



BEAM DESIGN FORMULAS WITH SHEAR AND MOMENT DIAGRAMS



DESIGN AID No. 6

**American
Forest &
Paper
Association**

BEAM FORMULAS WITH SHEAR AND MOMENT DIAGRAMS

The American Wood Council (AWC) is part of the wood products group of the American Forest & Paper Association (AF&PA). AF&PA is the national trade association of the forest, paper, and wood products industry, representing member companies engaged in growing, harvesting, and processing wood and wood fiber, manufacturing pulp, paper, and paperboard products from both virgin and recycled fiber, and producing engineered and traditional wood products. For more information see www.afandpa.org.

While every effort has been made to insure the accuracy of the information presented, and special effort has been made to assure that the information reflects the state-of-the-art, neither the American Forest & Paper Association nor its members assume any responsibility for any particular design prepared from this publication. Those using this document assume all liability from its use.

Copyright © 2007
American Forest & Paper Association, Inc.

American Wood Council
1111 19th St., NW, Suite 800
Washington, DC 20036
202-463-4713

awcinfo@afandpa.org

www.awc.org

AMERICAN WOOD COUNCIL

Introduction

Figures 1 through 32 provide a series of shear and moment diagrams with accompanying formulas for design of beams under various static loading conditions.

Shear and moment diagrams and formulas are excerpted from the *Western Woods Use Book*, 4th edition, and are provided herein as a courtesy of [Western Wood Products Association](#).


Notations Relative to “Shear and Moment Diagrams”

- E = modulus of elasticity, psi
- I = moment of inertia, in.⁴
- L = span length of the bending member, ft.
- ℓ = span length of the bending member, in.
- M = maximum bending moment, in.-lbs.
- P = total concentrated load, lbs.
- R = reaction load at bearing point, lbs.
- V = shear force, lbs.
- W = total uniform load, lbs.
- w = load per unit length, lbs./in.
- Δ = deflection or deformation, in.
- x = horizontal distance from reaction to point on beam, in.

List of Figures

Figure 1	Simple Beam – Uniformly Distributed Load	4
Figure 2	Simple Beam – Uniform Load Partially Distributed	4
Figure 3	Simple Beam – Uniform Load Partially Distributed at One End	5
Figure 4	Simple Beam – Uniform Load Partially Distributed at Each End	5
Figure 5	Simple Beam – Load Increasing Uniformly to One End	6
Figure 6	Simple Beam – Load Increasing Uniformly to Center	6
Figure 7	Simple Beam – Concentrated Load at Center	7
Figure 8	Simple Beam – Concentrated Load at Any Point	7
Figure 9	Simple Beam – Two Equal Concentrated Loads Symmetrically Placed	8
Figure 10	Simple Beam – Two Equal Concentrated Loads Unsymmetrically Placed	8
Figure 11	Simple Beam – Two Unequal Concentrated Loads Unsymmetrically Placed	9
Figure 12	Cantilever Beam – Uniformly Distributed Load	9
Figure 13	Cantilever Beam – Concentrated Load at Free End	10
Figure 14	Cantilever Beam – Concentrated Load at Any Point	10
Figure 15	Beam Fixed at One End, Supported at Other – Uniformly Distributed Load	11
Figure 16	Beam Fixed at One End, Supported at Other – Concentrated Load at Center	11
Figure 17	Beam Fixed at One End, Supported at Other – Concentrated Load at Any Point	12
Figure 18	Beam Overhanging One Support – Uniformly Distributed Load	12
Figure 19	Beam Overhanging One Support – Uniformly Distributed Load on Overhang	13
Figure 20	Beam Overhanging One Support – Concentrated Load at End of Overhang	13
Figure 21	Beam Overhanging One Support – Concentrated Load at Any Point Between Supports	14
Figure 22	Beam Overhanging Both Supports – Unequal Overhangs – Uniformly Distributed Load	14
Figure 23	Beam Fixed at Both Ends – Uniformly Distributed Load	15
Figure 24	Beam Fixed at Both Ends – Concentrated Load at Center	15
Figure 25	Beam Fixed at Both Ends – Concentrated Load at Any Point	16
Figure 26	Continuous Beam – Two Equal Spans – Uniform Load on One Span	16
Figure 27	Continuous Beam – Two Equal Spans – Concentrated Load at Center of One Span	17
Figure 28	Continuous Beam – Two Equal Spans – Concentrated Load at Any Point	17
Figure 29	Continuous Beam – Two Equal Spans – Uniformly Distributed Load	18
Figure 30	Continuous Beam – Two Equal Spans – Two Equal Concentrated Loads Symmetrically Placed	18
Figure 31	Continuous Beam – Two Unequal Spans – Uniformly Distributed Load	19
Figure 32	Continuous Beam – Two Unequal Spans – Concentrated Load on Each Span Symmetrically Placed	19

Figure 1 Simple Beam – Uniformly Distributed Load



$$R = V \dots \dots \dots = \frac{w\ell}{2}$$

$$V_x \dots \dots \dots = w\left(\frac{\ell}{2} - x\right)$$


$$M_{\max} \text{ (at center)} \dots \dots \dots = \frac{w\ell^2}{8}$$

$$M_x \dots \dots \dots = \frac{wx}{2}(\ell - x)$$

$$\Delta_{\max} \text{ (at center)} \dots \dots \dots = \frac{5w\ell^4}{384EI}$$

$$\Delta_x \dots \dots \dots = \frac{wx}{24EI}(\ell^3 - 2\ell x^2 + x^3)$$

Figure 2 Simple Beam – Uniform Load Partially Distributed



$$R_1 = V_1 \text{ (max when } a < c) \dots \dots = \frac{wb}{2\ell}(2c + b)$$

$$R_2 = V_2 \text{ (max when } a > c) \dots \dots = \frac{wb}{2\ell}(2a + b)$$

$$V_x \text{ (when } x > a \text{ and } < (a + b)) \dots \dots = R_1 - w(x - a)$$


$$M_{\max} \left(\text{at } x = a + \frac{R_1}{w} \right) \dots \dots = R_1 \left(a + \frac{R_1}{2w} \right)$$

$$M_x \text{ (when } x < a) \dots \dots \dots = R_1 x$$

$$M_x \text{ (when } x > a \text{ and } < (a + b)) \dots \dots = R_1 x - \frac{w}{2}(x - a)^2$$

$$M_x \text{ (when } x > (a + b)) \dots \dots \dots = R_2(\ell - x)$$

Figure 3 Simple Beam – Uniform Load Partially Distributed at One End



$$R_1 = V_1 \dots\dots\dots = \frac{wa}{2\ell}(2\ell - a)$$

$$R_2 = V_2 \dots\dots\dots = \frac{wa^2}{2\ell}$$

$$V_x \text{ (when } x < a) \dots\dots\dots = R_1 - wx$$

$$M_{\max} \left(\text{at } x = \frac{R_1}{w} \right) \dots\dots\dots = \frac{R_1^2}{2w}$$


$$M_x \text{ (when } x < a) \dots\dots\dots = R_1x - \frac{wx^2}{2}$$

$$M_x \text{ (when } x > a) \dots\dots\dots = R_2(\ell - x)$$

$$\Delta_x \text{ (when } x < a) \dots\dots\dots = \frac{wx}{24 E I \ell} (a^2(2\ell - a)^2 - 2ax^2(2\ell - a) + \ell x^3)$$

$$\Delta_x \text{ (when } x > a) \dots\dots\dots = \frac{wa^2(\ell - x)}{24 E I \ell} (4x\ell - 2x^2 - a^2)$$

Figure 4 Simple Beam – Uniform Load Partially Distributed at Each End



$$R_1 = V_1 \dots\dots\dots = \frac{w_1a(2\ell - a) + w_2c^2}{2\ell}$$

$$R_2 = V_2 \dots\dots\dots = \frac{w_2c(2\ell - c) + w_1a^2}{2\ell}$$

$$V_x \text{ (when } x < a) \dots\dots\dots = R_1 - w_1x$$

$$V_x \text{ (when } x > a \text{ and } < (a + b)) \dots\dots\dots = R_1 - w_1a$$

$$V_x \text{ (when } x > (a + b)) \dots\dots\dots = R_2 - w_2(\ell - x)$$

$$M_{\max} \left(\text{at } x = \frac{R_1}{w_1} \text{ when } R_1 < w_1a \right) \dots\dots\dots = \frac{R_1^2}{2w_1}$$


$$M_{\max} \left(\text{at } x = \ell - \frac{R_2}{w_2} \text{ when } R_2 < w_2c \right) = \frac{R_2^2}{2w_2}$$

$$M_x \text{ (when } x < a) \dots\dots\dots = R_1x - \frac{w_1x^2}{2}$$

$$M_x \text{ (when } x > a \text{ and } < (a + b)) \dots\dots\dots = R_1x - \frac{w_1a}{2}(2x - a)$$

$$M_x \text{ (when } x > (a + b)) \dots\dots\dots = R_2(\ell - x) - \frac{w_2(\ell - x)^2}{2}$$

Figure 5 Simple Beam – Load Increasing Uniformly to One End



$$R_1 = V_1 \dots \dots \dots = \frac{W}{3}$$

$$R_2 = V_2 \dots \dots \dots = \frac{2W}{3}$$

$$V_x \dots \dots \dots = \frac{W}{3} - \frac{Wx^2}{\ell^2}$$


$$M_{\max} \left(\text{at } x = \frac{\ell}{\sqrt{3}} = .5774\ell \right) \dots \dots = \frac{2W\ell}{9\sqrt{3}} = .1283W\ell$$

$$M_x \dots \dots \dots = \frac{Wx}{3\ell^2} (\ell^2 - x^2)$$

$$\Delta_{\max} \left(\text{at } x = \ell \sqrt{1 - \sqrt{\frac{8}{15}}} = .5193\ell \right) \dots = .01304 \frac{W\ell^3}{EI}$$

$$\Delta_x \dots \dots \dots = \frac{Wx}{180EI\ell^2} (3x^4 - 10\ell^2x^2 + 7\ell^4)$$

Figure 6 Simple Beam – Load Increasing Uniformly to Center



$$R = V \dots \dots \dots = \frac{W}{2}$$

$$V_x \left(\text{when } x < \frac{\ell}{2} \right) \dots \dots \dots = \frac{W}{2\ell^2} (\ell^2 - 4x^2)$$


$$M_{\max} \left(\text{at center} \right) \dots \dots \dots = \frac{W\ell}{6}$$

$$M_x \left(\text{when } x < \frac{\ell}{2} \right) \dots \dots \dots = Wx \left(\frac{1}{2} - \frac{2x^2}{3\ell^2} \right)$$

$$\Delta_{\max} \left(\text{at center} \right) \dots \dots \dots = \frac{W\ell^3}{60EI}$$

$$\Delta_x \dots \dots \dots = \frac{Wx}{480EI\ell^2} (5\ell^2 - 4x^2)^2$$

Figure 7 Simple Beam – Concentrated Load at Center



$$R = V \dots\dots\dots = \frac{P}{2}$$


$$M_{\max} \text{ (at point of load)} \dots\dots\dots = \frac{P\ell}{4}$$

$$M_x \text{ (when } x < \frac{\ell}{2} \text{)} \dots\dots\dots = \frac{Px}{2}$$

$$\Delta_{\max} \text{ (at point of load)} \dots\dots\dots = \frac{P\ell^3}{48EI}$$

$$\Delta_x \text{ (when } x < \frac{\ell}{2} \text{)} \dots\dots\dots = \frac{Px}{48EI} (3\ell^2 - 4x^2)$$

Figure 8 Simple Beam – Concentrated Load at Any Point



$$R_1 = V_1 \text{ (max when } a < b \text{)} \dots\dots\dots = \frac{Pb}{\ell}$$

$$R_2 = V_2 \text{ (max when } a > b \text{)} \dots\dots\dots = \frac{Pa}{\ell}$$

$$M_{\max} \text{ (at point of load)} \dots\dots\dots = \frac{Pab}{\ell}$$

$$M_x \text{ (when } x < a \text{)} \dots\dots\dots = \frac{Pbx}{\ell}$$


$$\Delta_{\max} \left(\text{at } x = \sqrt{\frac{a(a+2b)}{3}} \text{ when } a > b \right) \dots\dots\dots = \frac{Pab(a+2b)\sqrt{3a(a+2b)}}{27EI\ell}$$

$$\Delta_a \text{ (at point of load)} \dots\dots\dots = \frac{Pa^2b^2}{3EI\ell}$$

$$\Delta_x \text{ (when } x < a \text{)} \dots\dots\dots = \frac{Pbx}{6EI\ell} (\ell^2 - b^2 - x^2)$$

$$\Delta_x \text{ (when } x > a \text{)} \dots\dots\dots = \frac{Pa(\ell - x)}{6EI\ell} (2\ell x - x^2 - a^2)$$

Figure 9 Simple Beam – Two Equal Concentrated Loads Symmetrically Placed



$$R = V \dots \dots \dots = P$$

$$M_{max} \text{ (between loads)} \dots \dots \dots = Pa$$


$$M_x \text{ (when } x < a) \dots \dots \dots = Px$$

$$\Delta_{max} \text{ (at center)} \dots \dots \dots = \frac{Pa}{24EI} (3l^2 - 4a^2)$$

$$\Delta_x \text{ (when } x < a) \dots \dots \dots = \frac{Px}{6EI} (3la - 3a^2 - x^2)$$

$$\Delta_x \text{ (when } x > a \text{ and } < (l - a)) \dots \dots = \frac{Pa}{6EI} (3lx - 3x^2 - a^2)$$

Figure 10 Simple Beam – Two Equal Concentrated Loads Unsymmetrically Placed



$$R_1 = V_1 \text{ (max when } a < b) \dots \dots \dots = \frac{P}{l} (l - a + b)$$

$$R_2 = V_2 \text{ (max when } a > b) \dots \dots \dots = \frac{P}{l} (l - b + a)$$

$$V_x \text{ (when } x > a \text{ and } < (l - b)) \dots \dots = \frac{P}{l} (b - a)$$


$$M_1 \text{ (max when } a > b) \dots \dots \dots = R_1 a$$

$$M_2 \text{ (max when } a < b) \dots \dots \dots = R_2 b$$

$$M_x \text{ (when } x < a) \dots \dots \dots = R_1 x$$

$$M_x \text{ (when } x > a \text{ and } < (l - b)) \dots \dots = R_1 x - P(x - a)$$

Figure 11 Simple Beam – Two Unequal Concentrated Loads Unsymmetrically Placed



$$R_1 = V_1 \dots \dots \dots = \frac{P_1(\ell - a) + P_2 b}{\ell}$$

$$R_2 = V_2 \dots \dots \dots = \frac{P_1 a + P_2(\ell - b)}{\ell}$$

$$V_x \text{ (when } x > a \text{ and } < (\ell - b)) \dots \dots = R_1 - P_1$$


$$M_1 \text{ (max when } R_1 < P_1) \dots \dots \dots = R_1 a$$

$$M_2 \text{ (max when } R_2 < P_2) \dots \dots \dots = R_2 b$$

$$M_x \text{ (when } x < a) \dots \dots \dots = R_1 x$$

$$M_x \text{ (when } x > a \text{ and } < (\ell - b)) \dots \dots = R_1 x - P_1(x - a)$$

Figure 12 Cantilever Beam – Uniformly Distributed Load



$$R = V \dots \dots \dots = w\ell$$

$$V_x \dots \dots \dots = wx$$


$$M_{\max} \text{ (at fixed end)} \dots \dots \dots = \frac{w\ell^2}{2}$$

$$M_x \dots \dots \dots = \frac{wx^2}{2}$$

$$\Delta_{\max} \text{ (at free end)} \dots \dots \dots = \frac{w\ell^4}{8EI}$$

$$\Delta_x \dots \dots \dots = \frac{w}{24EI} (x^4 - 4\ell^3 x + 3\ell^4)$$

Figure 13 Cantilever Beam – Concentrated Load at Free End



$$R = V \dots \dots \dots = P$$


$$M_{\max} \text{ (at fixed end)} \dots \dots \dots = P\ell$$

$$M_x \dots \dots \dots = Px$$

$$\Delta_{\max} \text{ (at free end)} \dots \dots \dots = \frac{P\ell^3}{3EI}$$

$$\Delta_x \dots \dots \dots = \frac{P}{6EI} (2\ell^3 - 3\ell^2x + x^3)$$

Figure 14 Cantilever Beam – Concentrated Load at Any Point



$$R = V \dots \dots \dots = P$$

$$M_{\max} \text{ (at fixed end)} \dots \dots \dots = Pb$$

$$M_x \text{ (when } x > a) \dots \dots \dots = P(x - a)$$


$$\Delta_{\max} \text{ (at free end)} \dots \dots \dots = \frac{Pb^2}{6EI} (3\ell - b)$$

$$\Delta_a \text{ (at point of load)} \dots \dots \dots = \frac{Pb^3}{3EI}$$

$$\Delta_x \text{ (when } x < a) \dots \dots \dots = \frac{Pb^2}{6EI} (3\ell - 3x - b)$$


$$\Delta_x \text{ (when } x > a) \dots \dots \dots = \frac{P(\ell - x)^2}{6EI} (3b - \ell + x)$$

Figure 15 Beam Fixed at One End, Supported at Other – Uniformly Distributed Load




$$\begin{aligned}
 R_1 = V_1 & \dots \dots \dots = \frac{3w\ell}{8} \\
 R_2 = V_2 & \dots \dots \dots = \frac{5w\ell}{8} \\
 V_x & \dots \dots \dots = R_1 - wx \\
 M_{\max} & \dots \dots \dots = \frac{w\ell^2}{8} \\
 M_1 \left(\text{at } x = \frac{3}{8} \ell \right) & \dots \dots \dots = \frac{9}{128} w\ell^2 \\
 M_x & \dots \dots \dots = R_1 x - \frac{wx^2}{2} \\
 \Delta_{\max} \left(\text{at } x = \frac{\ell}{16} (1 + \sqrt{33}) = .4215 \ell \right) & \dots \dots \dots = \frac{w\ell^4}{185EI} \\
 \Delta_x & \dots \dots \dots = \frac{wx}{48EI} (\ell^3 - 3\ell x^2 + 2x^3)
 \end{aligned}$$

Figure 16 Beam Fixed at One End, Supported at Other – Concentrated Load at Center



$$\begin{aligned}
 R_1 = V_1 & \dots \dots \dots = \frac{5P}{16} \\
 R_2 = V_2 & \dots \dots \dots = \frac{11P}{16} \\
 M_{\max} \text{ (at fixed end)} & \dots \dots \dots = \frac{3P\ell}{16} \\
 M_1 \text{ (at point of load)} & \dots \dots \dots = \frac{5P\ell}{32} \\
 M_x \left(\text{when } x < \frac{\ell}{2} \right) & \dots \dots \dots = \frac{5Px}{16} \\
 M_x \left(\text{when } x > \frac{\ell}{2} \right) & \dots \dots \dots = P \left(\frac{\ell}{2} - \frac{11x}{16} \right) \\
 \Delta_{\max} \left(\text{at } x = \ell \sqrt{\frac{1}{5}} = .4472\ell \right) & \dots \dots \dots = \frac{P\ell^3}{48EI\sqrt{5}} = .009317 \frac{P\ell^3}{EI} \\
 \Delta_x \text{ (at point of load)} & \dots \dots \dots = \frac{7P\ell^3}{768EI} \\
 \Delta_x \left(\text{when } x < \frac{\ell}{2} \right) & \dots \dots \dots = \frac{Px}{96EI} (3\ell^2 - 5x^2) \\
 \Delta_x \left(\text{when } x > \frac{\ell}{2} \right) & \dots \dots \dots = \frac{P}{96EI} (x - \ell)^2 (11x - 2\ell)
 \end{aligned}$$

Figure 17 Beam Fixed at One End, Supported at Other – Concentrated Load at Any Point



$$R_1 = V_1 \dots \dots \dots = \frac{Pb^2}{2\ell^3}(a + 2\ell)$$

$$R_2 = V_2 \dots \dots \dots = \frac{Pa}{2\ell^3}(3\ell^2 - a^2)$$

$$M_1 \text{ (at point of load)} \dots \dots \dots = R_1 a$$

$$M_2 \text{ (at fixed end)} \dots \dots \dots = \frac{Pab}{2\ell^2}(a + \ell)$$

$$M_x \text{ (when } x < a) \dots \dots \dots = R_1 x$$

$$M_x \text{ (when } x > a) \dots \dots \dots = R_1 x - P(x - a)$$

$$\Delta_{\max} \left(\text{when } a < .414\ell \text{ at } x = \ell \frac{\ell^2 + a^2}{3\ell^2 - a^2} \right) = \frac{Pa}{3EI} \frac{(\ell^2 - a^2)^3}{(3\ell^2 - a^2)^2}$$


$$\Delta_{\max} \left(\text{when } a > .414\ell \text{ at } x = \ell \sqrt{\frac{a}{2\ell + a}} \right) = \frac{Pab^2}{6EI} \sqrt{\frac{a}{2\ell + a}}$$

$$\Delta_a \text{ (at point of load)} \dots \dots \dots = \frac{Pa^2 b^3}{12EI\ell^3}(3\ell + a)$$

$$\Delta_x \text{ (when } x < a) \dots \dots \dots = \frac{Pb^2 x}{12EI\ell^3}(3a\ell^2 - 2\ell x^2 - ax^2)$$

$$\Delta_x \text{ (when } x > a) \dots \dots \dots = \frac{Pa}{12EI\ell^3}(\ell - x)^2(3\ell^2 x - a^2 x - 2a^2 \ell)$$

Figure 18 Beam Overhanging One Support – Uniformly Distributed Load



$$R_1 = V_1 \dots \dots \dots = \frac{w}{2\ell}(\ell^2 - a^2)$$

$$R_2 = V_2 + V_3 \dots \dots \dots = \frac{w}{2\ell}(\ell + a)^2$$

$$V_2 \dots \dots \dots = wa$$

$$V_3 \dots \dots \dots = \frac{w}{2\ell}(\ell^2 + a^2)$$

$$V_x \text{ (between supports)} \dots \dots \dots = R_1 - wx$$

$$V_{x_1} \text{ (for overhang)} \dots \dots \dots = w(a - x_1)$$

$$M_1 \left(\text{at } x = \frac{\ell}{2} \left[1 - \frac{a^2}{\ell^2} \right] \right) \dots \dots \dots = \frac{w}{8\ell^2}(\ell + a)^2(\ell - a)^2$$

$$M_2 \text{ (at } R_2) \dots \dots \dots = \frac{wa^2}{2}$$


$$M_x \text{ (between supports)} \dots \dots \dots = \frac{wx}{2\ell}(\ell^2 - a^2 - x\ell)$$

$$M_{x_1} \text{ (for overhang)} \dots \dots \dots = \frac{w}{2}(a - x_1)^2$$

$$\Delta_x \text{ (between supports)} \dots \dots \dots = \frac{wx}{24EI\ell}(\ell^4 - 2\ell^2 x^2 + \ell x^3 - 2a^2 \ell^2 + 2a^2 x^2)$$

$$\Delta_{x_1} \text{ (for overhang)} \dots \dots \dots = \frac{wx_1}{24EI}(4a^2 \ell - \ell^3 + 6a^2 x_1 - 4ax_1^2 + x_1^3)$$

Figure 19 Beam Overhanging One Support – Uniformly Distributed Load on Overhang



$$R_1 = V_1 \dots \dots \dots = \frac{wa^2}{2\ell}$$

$$R_2 = V_1 + V_2 \dots \dots \dots = \frac{wa}{2\ell}(2\ell + a)$$

$$V_2 \dots \dots \dots = wa$$

$$V_{x_1} \text{ (for overhang)} \dots \dots \dots = w(a - x_1)$$

$$M_{\max} \text{ (at } R_2) \dots \dots \dots = \frac{wa^2}{2}$$

$$M_x \text{ (between supports)} \dots \dots \dots = \frac{wa^2x}{2\ell}$$

$$M_{x_1} \text{ (for overhang)} \dots \dots \dots = \frac{w}{2}(a - x_1)^2$$


$$\Delta_{\max} \left(\text{between supports at } x = \frac{\ell}{\sqrt{3}} \right) = \frac{wa^2\ell^2}{18\sqrt{3}EI} = .03208 \frac{wa^2\ell^2}{EI}$$

$$\Delta_{\max} \text{ (for overhang at } x_1 = a) \dots \dots = \frac{wa^3}{24EI}(4\ell + 3a)$$

$$\Delta_x \text{ (between supports)} \dots \dots \dots = \frac{wa^2x}{12EI\ell}(\ell^2 - x^2)$$

$$\Delta_{x_1} \text{ (for overhang)} \dots \dots \dots = \frac{wx_1}{24EI}(4a^2\ell + 6ax_1 - 4ax_1^2 + x_1^3)$$

Figure 20 Beam Overhanging One Support – Concentrated Load at End of Overhang



$$R_1 = V_1 \dots \dots \dots = \frac{Pa}{\ell}$$

$$R_2 = V_1 + V_2 \dots \dots \dots = \frac{P}{\ell}(\ell + a)$$

$$V_2 \dots \dots \dots = P$$

$$M_{\max} \text{ (at } R_2) \dots \dots \dots = Pa$$

$$M_x \text{ (between supports)} \dots \dots \dots = \frac{Pax}{\ell}$$

$$M_{x_1} \text{ (for overhang)} \dots \dots \dots = P(a - x_1)$$


$$\Delta_{\max} \left(\text{between supports at } x = \frac{\ell}{\sqrt{3}} \right) = \frac{Pal^2}{9\sqrt{3}EI} = .06415 \frac{Pal^2}{EI}$$

$$\Delta_{\max} \text{ (for overhang at } x_1 = a) \dots \dots = \frac{Pa^2}{3EI}(\ell + a)$$

$$\Delta_x \text{ (between supports)} \dots \dots \dots = \frac{Pax}{6EI\ell}(\ell^2 - x^2)$$

$$\Delta_{x_1} \text{ (for overhang)} \dots \dots \dots = \frac{Px_1}{6EI}(2a\ell + 3ax_1 - x_1^2)$$

Figure 21 Beam Overhanging One Support – Concentrated Load at Any Point Between Supports



$$R_1 = V_1 \text{ (max when } a < b) \dots \dots \dots = \frac{Pb}{l}$$

$$R_2 = V_2 \text{ (max when } a > b) \dots \dots \dots = \frac{Pa}{l}$$

$$M_{max} \text{ (at point of load)} \dots \dots \dots = \frac{Pab}{l}$$

$$M_x \text{ (when } x < a) \dots \dots \dots = \frac{Pbx}{l}$$

$$\Delta_{max} \left(\text{at } x = \sqrt{\frac{a(a+2b)}{3}} \text{ when } a > b \right) \dots \dots \dots = \frac{Pab(a+2b)\sqrt{3a(a+2b)}}{27EI\ell}$$


$$\Delta_a \text{ (at point of load)} \dots \dots \dots = \frac{Pa^2b^2}{3EI\ell}$$

$$\Delta_x \text{ (when } x < a) \dots \dots \dots = \frac{Pbx}{6EI\ell} (\ell^2 - b^2 - x^2)$$

$$\Delta_x \text{ (when } x > a) \dots \dots \dots = \frac{Pa(\ell - x)}{6EI\ell} (2\ell x - x^2 - a^2)$$

$$\Delta_{x_1} \dots \dots \dots = \frac{Pabx_1}{6EI\ell} (\ell + a)$$

Figure 22 Beam Overhanging Both Supports – Unequal Overhangs – Uniformly Distributed Load



$$R_1 \dots \dots \dots = \frac{w\ell(\ell - 2c)}{2b}$$

$$R_2 \dots \dots \dots = \frac{w\ell(\ell - 2a)}{2b}$$

$$V_1 \dots \dots \dots = wa$$

$$V_2 \dots \dots \dots = R_1 - V_1$$

$$V_3 \dots \dots \dots = R_2 - V_4$$

$$V_4 \dots \dots \dots = wc$$

$$V_{x_1} \dots \dots \dots = V_1 - wx_1$$

$$V_x \text{ (when } x < \ell) \dots \dots \dots = R_1 - w(a + x_1)$$

$$V_m \text{ (when } a < c) \dots \dots \dots = R_2 - wc$$


$$M_1 \dots \dots \dots = -\frac{wa^2}{2}$$

$$M_2 \dots \dots \dots = -\frac{wc^2}{2}$$

$$M_3 \dots \dots \dots = R_1 \left(\frac{R_1}{2w} - a \right)$$

$$M_x \left(\text{max when } x = \frac{R_1}{w} - a \right) \dots \dots \dots = R_1 x - \frac{w(a+x)^2}{2}$$

Figure 23 Beam Fixed at Both Ends – Uniformly Distributed Load



$$R = V \dots \dots \dots = \frac{wl}{2}$$

$$V_x \dots \dots \dots = w\left(\frac{\ell}{2} - x\right)$$

$$M_{\max} \text{ (at ends)} \dots \dots \dots = \frac{wl^2}{12}$$


$$M_1 \text{ (at center)} \dots \dots \dots = \frac{wl^2}{24}$$

$$M_x \dots \dots \dots = \frac{w}{12}(6\ell x - \ell^2 - 6x^2)$$

$$\Delta_{\max} \text{ (at center)} \dots \dots \dots = \frac{wl^4}{384EI}$$

$$\Delta_x \dots \dots \dots = \frac{wx^2}{24EI}(\ell - x)^2$$

Figure 24 Beam Fixed at Both Ends – Concentrated Load at Center



$$R = V \dots \dots \dots = \frac{P}{2}$$


$$M_{\max} \text{ (at center and ends)} \dots \dots \dots = \frac{Pl}{8}$$

$$M_x \left(\text{when } x < \frac{\ell}{2} \right) \dots \dots \dots = \frac{P}{8}(4x - \ell)$$

$$\Delta_{\max} \text{ (at center)} \dots \dots \dots = \frac{Pl^3}{192EI}$$

$$\Delta_x \left(\text{when } x < \frac{\ell}{2} \right) \dots \dots \dots = \frac{Px^2}{48EI}(3\ell - 4x)$$

Figure 25 Beam Fixed at Both Ends – Concentrated Load at Any Point



$$R_1 = V_1 \text{ (max when } a < b) \dots \dots \dots = \frac{Pb^2}{\ell^3} (3a + b)$$

$$R_2 = V_2 \text{ (max when } a > b) \dots \dots \dots = \frac{Pa^2}{\ell^3} (a + 3b)$$

$$M_1 \text{ (max when } a < b) \dots \dots \dots = \frac{Pab^2}{\ell^2}$$

$$M_2 \text{ (max when } a > b) \dots \dots \dots = \frac{Pa^2b}{\ell^2}$$

$$M_a \text{ (at point of load) } \dots \dots \dots = \frac{2Pa^2b^2}{\ell^3}$$


$$M_x \text{ (when } x < a) \dots \dots \dots = R_1x - \frac{Pbx}{\ell^2}$$

$$\Delta_{\max} \left(\text{when } a > b \text{ at } x = \frac{2a\ell}{3a + b} \right) \dots \dots = \frac{2Pa^3b^2}{3EI(3a + b)^2}$$

$$\Delta_a \text{ (at point of load) } \dots \dots \dots = \frac{Pa^3b^3}{3EI\ell^3}$$

$$\Delta_x \text{ (when } x < a) \dots \dots \dots = \frac{Pb^2x^2}{6EI\ell^3} (3a\ell - 3ax - bx)$$

Figure 26 Continuous Beam – Two Equal Spans – Uniform Load on One Span



$$R_1 = V_1 \dots \dots \dots = \frac{7}{16} w\ell$$

$$R_2 = V_2 + V_3 \dots \dots \dots = \frac{5}{8} w\ell$$

$$R_3 = V_3 \dots \dots \dots = -\frac{1}{16} w\ell$$


$$V_2 \dots \dots \dots = \frac{9}{16} w\ell$$

$$M_{\max} \left(\text{at } x = \frac{7}{16} \ell \right) \dots \dots \dots = \frac{49}{512} w\ell^2$$

$$M_1 \text{ (at support } R_2) \dots \dots \dots = \frac{1}{16} w\ell^2$$

$$M_x \text{ (when } x < \ell) \dots \dots \dots = \frac{wx}{16} (7\ell - 8x)$$

Figure 27 Continuous Beam – Two Equal Spans – Concentrated Load at Center of One Span



$$R_1 = V_1 \dots\dots\dots = \frac{13}{32} P$$

$$R_2 = V_2 + V_3 \dots\dots\dots = \frac{11}{16} P$$


$$R_3 = V_3 \dots\dots\dots = -\frac{3}{32} P$$

$$V_2 \dots\dots\dots = \frac{19}{32} P$$

$$M_{\max} \text{ (at point of load)} \dots\dots\dots = \frac{13}{64} P\ell$$

$$M_1 \text{ (at support } R_2) \dots\dots\dots = \frac{3}{32} P\ell$$

Figure 28 Continuous Beam – Two Equal Spans – Concentrated Load at Any Point



$$R_1 = V_1 \dots\dots\dots = \frac{Pb}{4\ell^3} (4\ell^2 - a(\ell + a))$$

$$R_2 = V_2 + V_3 \dots\dots\dots = \frac{Pa}{2\ell^3} (2\ell^2 + b(\ell + a))$$


$$R_3 = V_3 \dots\dots\dots = -\frac{Pab}{4\ell^3} (\ell + a)$$

$$V_2 \dots\dots\dots = \frac{Pa}{4\ell^3} (4\ell^2 + b(\ell + a))$$

$$M_{\max} \text{ (at point of load)} \dots\dots\dots = \frac{Pab}{4\ell^3} (4\ell^2 - a(\ell + a))$$


$$M_1 \text{ (at support } R_2) \dots\dots\dots = \frac{Pab}{4\ell^2} (\ell + a)$$

Figure 29 Continuous Beam – Two Equal Spans – Uniformly Distributed Load




$$\begin{aligned}
 R_1 = V_1 = R_3 = V_3 & \dots \dots \dots = \frac{3w\ell}{8} \\
 R_2 & \dots \dots \dots = \frac{10w\ell}{8} \\
 V_2 = V_{\max} & \dots \dots \dots = \frac{5w\ell}{8} \\
 M_1 & \dots \dots \dots = \frac{w\ell^2}{8} \\
 M_2 \left(\text{at } \frac{3\ell}{8} \right) & \dots \dots \dots = \frac{9w\ell^2}{128} \\
 \Delta_{\max} \left(\text{at } 0.4215\ell, \text{ approx. from } R_1 \text{ and } R_3 \right) & \dots \dots = \frac{w\ell^4}{185EI}
 \end{aligned}$$

Figure 30 Continuous Beam – Two Equal Spans – Two Equal Concentrated Loads Symmetrically Placed




$$\begin{aligned}
 R_1 = V_1 = R_3 = V_3 & \dots \dots \dots = \frac{5P}{16} \\
 R_2 = 2V_2 & \dots \dots \dots = \frac{11P}{8} \\
 V_2 = P - R_1 & \dots \dots \dots = \frac{11P}{16} \\
 V_{\max} & \dots \dots \dots = V_2 \\
 M_1 & \dots \dots \dots = -\frac{3P\ell}{16} \\
 M_2 & \dots \dots \dots = \frac{5P\ell}{32} \\
 M_x \text{ (when } x < a) & \dots \dots \dots = R_1x
 \end{aligned}$$

Figure 31 Continuous Beam – Two Unequal Spans – Uniformly Distributed Load



$$\begin{aligned}
 R_1 & \dots \dots \dots = \frac{M_1}{\ell_1} + \frac{w\ell_1}{2} \\
 R_2 & \dots \dots \dots = w\ell_1 + w\ell_2 - R_1 - R_3 \\
 R_3 = V_4 & \dots \dots \dots = \frac{M_1}{\ell_2} + \frac{w\ell_2}{2} \\
 V_1 & \dots \dots \dots = R_1 \\
 V_2 & \dots \dots \dots = w\ell_1 - R_1 \\
 V_3 & \dots \dots \dots = w\ell_2 - R_3 \\
 V_4 & \dots \dots \dots = R_3 \\
 M_1 & \dots \dots \dots = -\frac{w\ell_2^3 + w\ell_1^3}{8(\ell_1 + \ell_2)} \\
 M_{x_1} \left(\text{when } x_1 = \frac{R_1}{w} \right) & \dots \dots \dots = R_1 x_1 - \frac{w x_1^2}{2} \\
 M_{x_2} \left(\text{when } x_2 = \frac{R_3}{w} \right) & \dots \dots \dots = R_3 x_2 - \frac{w x_2^2}{2}
 \end{aligned}$$

Figure 32 Continuous Beam – Two Unequal Spans – Concentrated Load on Each Span Symmetrically Placed



$$\begin{aligned}
 R_1 & \dots \dots \dots = \frac{M_1}{\ell_1} + \frac{P_1}{2} \\
 R_2 & \dots \dots \dots = P_1 + P_2 - R_1 - R_3 \\
 R_3 & \dots \dots \dots = \frac{M_1}{\ell_2} + \frac{P_2}{2} \\
 V_1 & \dots \dots \dots = R_1 \\
 V_2 & \dots \dots \dots = P_1 - R_1 \\
 V_3 & \dots \dots \dots = P_2 - R_3 \\
 V_4 & \dots \dots \dots = R_3 \\
 M_1 & \dots \dots \dots = -\frac{3}{16} \left(\frac{P_1 \ell_1^2 + P_2 \ell_2^2}{\ell_1 + \ell_2} \right) \\
 M_{m_1} & \dots \dots \dots = R_1 a \\
 M_{m_2} & \dots \dots \dots = R_3 b
 \end{aligned}$$

<http://aaitcivil.wordpress.com>

**American Forest & Paper Association
American Wood Council
1111 19th Street, NW
Suite 800
Washington, DC 20036
Phone: 202-463-4713
Fax: 202-463-2791
awcinfo@afandpa.org
www.awc.org**

A F & P A[®]

